



TOP Reproductions

Shift Indicator Cable

1980 – 1986

Ford F150, F250, F350 & Bronco

Contents:

- Indicator Cable
- #8 Hex Head Screws
- #8 Flat Head Screw
- Concave Retaining Washer

Instructions:

- Mount cable to indicator with #8 flat head screw
- Install indicator into the gauge cluster and install cluster into truck
- Mount cable to steering column using the concave retaining washer and a hex head screw. Leave screw loose enough for cable adjustment
- Move transmission shift lever to D position
- Adjust the column end of the cable so the indicator needle is over the D position and tighten the column screw
- Push tube retaining clip into the small hole on the right side of column