



# TOP Reproductions

## Shift Indicator Cable

1987 – 1991

Ford F150, F250, F350 & Bronco

### Contents:

- Indicator Cable
- #6 Head Head Screws
- #8-32 Hex Head Machine Screw
- Concave Retaining Washer

### Instructions:

- Mount cable to indicator using #6 hex head screw
- Attach spring and cable end over pivot arm
- Mount pivot arm to indicator. Make sure arm end is in hole on indicator slide.
- Attach other spring end to indicator
- Install indicator into the gauge cluster and install gauge cluster into truck
- Mount cable to steering column using the concave retaining washer and the #8-32 hex head screw. Leave screw loose enough for cable adjustment
- Move transmission shift lever to D position.
- Adjust the column end of the cable so the indicator shows D and tighten the column screw